



Note:  
 $D=W/2$ , Where D is the depth of the joint after backer rod placement and W is the joint width

<b>Architectural Detail</b>			
<b>Joint Isolation Detail</b> Expansion/Isolation Joint Treatment			
<b>STONHARD</b> 1000 East Park Avenue			
Maple Shade		New Jersey 08052	
Scale: NTS	Date: 06/30/2011	Drawing no.: MISC.006	Drawn by: KMB